



# HYDRO BAN<sup>®</sup> Linear Drain

DS-34-0620

**Globally Proven  
Construction Solutions**



## 1. PRODUCT NAME

HYDRO BAN<sup>®</sup> Linear Drain

## 2. MANUFACTURER

LATICRETE International, Inc.  
1 LATICRETE Park North  
Bethany, CT 06524-3423 USA

Telephone: +1.203.393.0010, ext. 1235

Toll Free: 1.800.243.4788, ext. 1235

Fax: +1.203.393.1684

Website: [laticrete.com](http://laticrete.com)

## 3. PRODUCT DESCRIPTION

HYDRO BAN Linear Drains are low profile linear floor drains specifically designed for bonded waterproofing installations with HYDRO BAN waterproofing membranes. The NEW HYDRO BAN Linear Drain Troughs are designed with a "V" slope to enhance drainage and can be paired with any HYDRO BAN Drain Grate, which are available in off-set oval with brushed, polished & oil-rubbed bronze finishes, tile-in or wedge wire in brushed or polished. The HYDRO BAN Linear Drain allows for the use of large format tile or stone installations in a shower with a single plane slope to the drain. The HYDRO BAN Linear Drain can be installed near the wall, entry or at medial locations in a variety of areas requiring waterproof applications. The HYDRO BAN Linear Drain is available with standard vertical waste line, a horizontal side outlet or a threaded connector for clamping ring drain installations. Trough and grates are sold separately. Custom sizes are available upon request.

## Uses

- Interior or exterior
- Showers
- Industrial, commercial and residential bathrooms and laundries
- Kitchens and food processing areas
- Terraces, decks and balconies

## Advantages

- Single slope to drain
- Allows for use of large format tile
- HYDRO BAN Linear Drains are designed with a "V" slope in the trough to enhance drainage
- Tile in grate available to match floor tile
- Eliminates pre-slope and primary shower pan for a faster installation
- Available in eight lengths and three grate styles
- Troughs and grates are sold separately to allow mixing and matching of grate style and trough design
- Made from heavy duty 304 stainless steel provides for long lasting performance
- HYDRO BAN waterproofing membrane bonds directly to stainless steel flange edge allowing for faster
- Easier installation

## Suitable Substrates

- Cement Backer Board
- Cement Mortar Bed
- Concrete
- HYDRO BAN Pre-Sloped Shower Pans
- Exterior Glue Plywood (Interior Only)

## Packaging

The HYDRO BAN Linear Drain is a two-piece drain with a trough and removable grate, sold separately. Available in eight lengths and three grate styles: offset oval in brushed, polished & oil-rubbed bronze finishes, wedge wire in brushed or polished stainless steel and a tile-in tray. HYDRO BAN Linear Drain Grates are supplied with a key for easy removal and cleaning. The HYDRO BAN Linear Drain Troughs are supplied with a hair strainer. The HYDRO BAN Linear Drain Grate and Troughs are available in the following lengths. The measurements are given as the actual grate length. Troughs are designed to accept these grates. Troughs are designed with a 1" (2.5 cm) continuous flange around the trough.

24" (61 cm)

30" (81 cm)  
32" (81 cm)  
36" (91 cm)  
42" (107 cm)  
48" (122 cm)  
54" (137 cm)  
60" (152 cm)

### Limitations

- Adhesives/mastics, mortars and grouts for ceramic tile, pavers, brick and stone are not replacements for waterproofing membranes. When a waterproofing membrane is required, use HYDRO BAN (see Section 10 FILING SYSTEMS).

### Cautions

- During cold weather, protect finished work from traffic until fully cured.
- All stainless steel surfaces must be clean and free of any dirt, oil, grease and fingerprints prior to coating with HYDRO BAN.

## 4. TECHNICAL DATA

### Applicable Standard

- Code approval per ASME A 112.18-2/CSA B125.2.05 (US and Canada)

### Working Properties

**The HYDRO BAN® Linear Drain series installs per IAPMO IGC 195. Waterproof using HYDRO BAN per TCNA B422.**

Specifications subject to change without notification. Results shown are typical but reflect test procedures used. Actual field performance will depend on installation methods and site conditions.

## 5. INSTALLATION

- **Surface Preparation** All surfaces should be between 40°F (4°C) and 90°F (32°C) and structurally sound, clean and free of all dirt, oil, grease, laitance, paint, concrete sealers or curing compounds. Dry dusty concrete slabs or masonry should be dampened and excess water swept off. Installation may be made on a damp surface. Expansion joints shall be provided through the tile work from all construction or expansion joints in the substrate.

Follow ANSI specification A108.01-3.7: Requirements for Movement Joints: Preparations by Other Trades" or TCNA detail EJ-171 "Movement joints-Vertical & Horizontal". Do not cover expansion joints with mortar.

Typically Linear Drains should run from sill plate to sill plate (the width of the shower) against a wall (see ES-B415LD Bonded Corner Placement). Alternatively they can also be placed in medial locations (see ES-

B415LD Unbonded Medial Placement) or at the shower entrance. In all locations the waste line for standard size HYDRO BAN Linear Drains are in the center of the linear drain. When installed against a wall the center of the waste line should be located far enough away from the sill plate to accommodate wall sheathing and finished tile surface.

For 1/2" (12 mm) wall board and 3/8" (9 mm) tile the center of the waste line should be located far enough away from the sill plate to accommodate wall sheathing and finished tile surface. For 1/2" (12mm) wall board and 3/8" (9 mm) tile the center of the waste line should be located 2 1/4" (57mm) out from the sill plate.

**Mortar Bed—Installation Over Concrete** (see ES-B415LD Bonded Corner Placement and ES-B415LD Unbonded Medial) for a Bonded mortar bed over concrete installation, before placing mortar, apply a slurry bond coat made from 254 Platinum. While the slurry bond coat is wet, spread 3701 Fortified Mortar and compact well. Bonded mortar beds over concrete shall be 3/4"(19 mm) minimum to 2"(50 mm) maximum. For an unbonded installation over concrete (see ES-415LD Unbonded Medial) a cleavage membrane as specified in ANSI A108.02-3.8 should be used in place of the slurry bond coat. The 3701 Fortified Mortar should be reinforced with 2" x 2" (50 x 50 mm) reinforcing mesh. Unbonded mortar beds over concrete shall be 1-1/4"(32 mm) minimum to 2"(50 mm) maximum. In both bonded and unbonded mortar Bed installations place enough 3701 Fortified Mortar where the linear drain will be set to support the bottom and under the flanges of the drain trough. Minimum height from the flange to the substrate should be 1-1/2" (38 mm).

Make the connection to the waste line when the drain is set into place using a no hub connection (not supplied), see installation instructions below. Next place a ribbon of 3701 Fortified Mortar along the opposite wall to create a 1/4" (6 mm) per foot slope to the HYDRO BAN Linear Drain. Fill the area between the drain and the walls with 3701 Fortified Mortar; screed and compact well. Mortar beds in excess of 2"(50 mm) thick shall be detailed by the architect per TCNA F112.

**Mortar Bed – Installation Over Exterior Glue Plywood (EGP)** (see ES-415LD EGP Bonded Corner Placement and ES-415LD EGP Unbonded Medial Placement) For a bonded mortar bed over EGP installation, before placing mortar, install a cleavage membrane as specified in ANSI A108.02-3.8. Expanded metal lath (minimum 2.5 pounds (1.1 kg)/square yard (0.8 square meters) and complying with ANSI A108.02 3.6) is then nailed or stapled to the subfloor over the cleavage membrane. Following the lath spread 3701 Fortified Mortar and compact well. Bonded mortar beds over EGP shall be 3/4"(19 mm)

minimum to 1 1/2"(38 mm) maximum. For an unbonded installation over EGP (see ES-415LD EGP Unbonded Medial Placement) install a cleavage membrane as specified in ANSI A108.02-3.8 and then spread the 3701 Fortified Mortar. In both bonded and unbonded mortar bed installations place enough 3701 Fortified Mortar where the linear drain will be set to support the bottom and under the flanges of the drain trough. Minimum height from the flange to the substrate should be 1-1/2" (38 mm). Make the connection to the waste line when the drain is set into place using a no hub connection (not supplied). Next place a ribbon of 3701 Fortified Mortar along the opposite wall to create a 1/4" (6 mm) per foot slope to the HYDRO BAN Linear Drain. Fill the area between the drain and the walls with 3701 Fortified Mortar; screed and compact well. Mortar beds in excess of 2"(50 mm) thick shall be detailed by the architect per TCNA F112.

### Installation Instructions (Fig. 1)

1. Connect outlet (D) to waste pipe (F) via 2"(50 mm) no hub connection using a rubber coupling (E) (not provided). **Note:** outlet section (D) is 3"(76 mm) long and can be modified for height adjustment. Grate A has adjustable feet for finer adjustment (Minimum tile height with thin-set is 3/8"(10 mm), maximum tile height is 3/4"(19 mm).

2. Using 3701 Fortified Mortar, set and level channel (C).

3. Spread 3701 Fortified Mortar, slope 1/4" per foot (19mm per m) to the drain in a single plane. **Note:** tile height should finish 1/16"(1.5 mm) higher than the grate height or the tile in the Tile in Drain Grate.

4. When the mortar is dry install backer board per manufacturer's instructions. The backer board will sit on the drain flange and mortar (see ES-B415LD Bonded Corner Placement or ES-B415LD EGP Bonded Corner Placement).

5. After the backer board has been installed waterproof the installation using HYDRO BAN per instructions in DS663.0 and DS663.5. The stainless steel needs to be clean and free of any grease, dirt or fingerprints prior to coating with HYDRO BAN. The HYDRO BAN should cover the metal flange on the linear drain trough to the top of the first radius and extend up the walls and over the entire mortar bed. If the gap between the linear drain flange and the wall board is larger than 1/8" (3 mm) it should be filled with a Polymer Modified Thin-Set (e.g. 254 Platinum). An alternative would be to use 6" (150 mm) wide Waterproofing/Anti-Fracture Fabric imbedded into the HYDRO BAN around four sides of the linear drain overlapping the flange and the 3701 Fortified Mortar. Lap Waterproofing/Anti-Fracture Fabric and HYDRO BAN liquid up the wall when adjacent to shower wall

and over wall board. When using Waterproofing/Anti-Fracture Fabric with HYDRO BAN to bridge a gap larger than 1/8" (3 mm) the gap should be filled with a Polymer Modified Thin-Set (e.g. 254 Platinum) prior to waterproofing. DO NOT waterproof the inside walls and bottom of the linear drain channels.

6. Take measures to protect grate (A) prior to tiling. Keeping the grate (A) in the channel (C), thin-set and tile on the waterproof membrane. Ensure tile allows for easy removal of the grate (A). The height should finish 1/16" (1.5 mm) higher than the grate height or tile in the tile-in drain grate.

7. If the grate has adjustable feet then adjust grate (A) height with adjustable feet (B) as needed.

8. When installing the HYDRO BAN® Linear Tile-In Drain Grate (A) will need to be primed with two coats of HYDRO BAN prior to thin-setting the tile into the top grate. The stainless steel from the linear drains needs to be clean and free of any grease, dirt or fingerprints prior to coating with HYDRO BAN.

9. When the second coat of HYDRO BAN is dry the installation can be tiled using a polymer fortified thin-set and grouted with PERMACOLOR® Grout. or SPECTRALOCK® PRO Premium Grout.




Fig. 1





Fig. 2

### Instructions to make a drain waste line connection with no access to tighten rubber coupling. Fig. 3

cut the 2" (50 mm) waste line (H) so the drain, a 2" (50 mm) rubber coupling (E), a length of 2" (50 mm) plastic pipe (F) (plastic pipe material should match waste line and plastic coupling material) and 2" (50 mm) plastic coupling (G) can be added to the drain outlet. Cement a 2" (50 mm) plastic coupling (G) to the length of the 2" (50 mm) diameter plastic pipe (F) using the appropriate cement for either PVC or ABS. Attach the rubber coupling (E) to the linear drain outlet and the length of 2" (50 mm) diameter plastic pipe (F). Tighten hose clamps on 2" (50 mm) rubber coupling (E). The final connection is made when the linear drain is installed by cementing the free end of the 2" (50 mm) diameter coupling (G) to the waste line (H). Side outlet drains will be installed the same as the vertical waste line connections except the plumbing connections will be made through the wall.



**Fig. 3**

**Installation Instructions (Fig. 4)** When a drain installation requires a clamping ring with a primary shower pan this can be provided as a custom HYDRO BAN Linear Drain with a 2" (50.8 mm) threaded nipple 1 1/2" (38.1 mm) length. The installation instructions are as follows in Fig. 4.

1. Install the clamping ring drain body (G) to the domestic waste line. Clamping ring drains can be provided in ABS, PVC or Cast Iron. The ABS and PVC will be connected using the appropriate ABS or PVC pipe cement with primer. The cast iron clamping ring drains can either have a no hub connection or a female pipe threaded connection.
2. Connect clamping ring drain to the waste outlet as appropriate for the clamping ring drain construction material: follow the adhesive instruction for ABS or PVC as required, if a cast iron drain is used connect with either a no hub rubber connector (not provided) using the hose clamps provided or wrap the threads on the waste line with Teflon tape and thread on the clamping ring drain body.
3. Install a pre-slope using 3701 Fortified Mortar from the lip of the clamping ring drain body out to the walls with a 2% slope. When the 3701 Fortified Mortar has dried apply two coats of HYDRO BAN liquid applied

waterproofing over the 3701 Fortified Mortar following DS 663.0 and 663.5. Install the clamping ring (E) as recommended with a bead of LATASIL™ under the clamping ring but over the cured HYDRO BAN. Tighten down the clamping ring using the hex head bolts (F) provided.

4. Thread the 2" (50 mm) stainless steel threaded nipple (D) into the clamping ring (E) to the desired height. Apply a bead of HYDRO BAN Adhesive & Sealant around the outside of the channel throat (C) and place the channel (B) into the stainless steel threaded nipple (D).
5. Pack 3701 Fortified Mortar around the channel (B) up to the height of the flange on the channel and slope to the opposite walls with a 2% slope (1/4" (6 mm) per 12" (305 mm)).

6. When the 3701 Fortified Mortar is dry install backer board per manufacturer's instructions. The backer board will sit on the drain flange and mortar (see ES-B415LD Bonded Corner Placement or ESB415LD EGP Bonded Corner Placement).

7. After the backer board has been installed waterproof the installation using HYDRO BAN per instructions in DS663.0 and DS663.5. The stainless steel needs to be clean and free of any grease, dirt or fingerprints prior to coating with HYDRO BAN®. The HYDRO BAN should cover the metal flange on the linear drain trough to the top of the first radius and extend up the walls and over the entire mortar bed. If the gap between the linear drain flange or the 3701 Fortified Mortar and the wall board is larger than 1/8" (3 mm) it should be filled with a Polymer Modified Thin-Set (e.g. 254 Platinum). An alternative would be to use 6" (150 mm) wide Waterproofing/Anti-Fracture Fabric imbedded into the HYDRO BAN® around four sides of the linear drain overlapping the flange and the 3701 Fortified Mortar. Lap Waterproofing/Anti-Fracture Fabric and HYDRO BAN liquid up the wall when adjacent to shower wall and over wall board. When using Waterproofing/Anti-Fracture Fabric with HYDRO BAN to bridge a gap larger than 1/8" (3 mm) the gap should be filled with a Polymer Modified Thin-Set (e.g. 254 Platinum) prior to waterproofing. DO NOT waterproof the inside walls and bottom of the linear drain channels.

8. Install either the offset oval grate of the tile-in grate as appropriate and set tile using 254 Platinum thin-set.
9. The offset oval grate has adjustable feet for finer adjustment (Minimum tile height with thin-set is 3/8"(10 mm), maximum tile height is 3/4"(19 mm). The tile-in grate does not have adjustable feet as they are not required. Note: tile height should finish 1/16"(1.5 mm) higher than the grate height or the tile in the Tile-In Grate.

10. Take measures to protect grate (A) prior to tiling. Keeping the grate (A) in the channel (B), thin-set and tile on the waterproof membrane. Ensure tile allows for easy removal of the grate (A). If the grate has adjustable feet then adjust grate (A) height with adjustable feet as needed.

11. When installing the HYDRO BAN Linear Tile-In Grate (A) will need to be primed with two coats of HYDRO BAN prior to thin-setting the tile into the top grate. The stainless steel from the linear drains needs to be clean and free of any grease, dirt or fingerprints prior to coating with HYDRO BAN.

12. When the second coat of HYDRO BAN is dry the installation can be tiled using a polymer fortified thin-set and grouted with PERMACOLOR® Grout or SPECTRALOCK® PRO Premium Grout.

### HYDRO BAN Linear Drain Clamping Ring Assembly




Fig. 4





Fig. 5 HYDRO BAN Hair Strainer

### Cleaning


Clean tools and tile work with water while the LATICRETE® products are fresh. NEVER use steel wool, wire brushes, chlorine bleach, hydrochloric acid (muriatic acid), or any chloride cleaners on stainless steel. Instead clean the polished and brushed stainless steel grates with commonly available products such as Bar Keepers Friend® or Soft Scrub®. The Oil Rubbed Bronze grates should only be cleaned with soap and warm water and light brushing with a soft bristle brush.




Drawing No. ES-B415LD –  
Bonded (Corner Placement)




Drawing No. ES-B415LD –  
Bonded (Corner Placement)



Drawing No. ES-B415LD –  
Unbonded Medial Placement



Drawing No. ES-B415LD –  
EGP Unbonded Medial Placement



## 6. AVAILABILITY AND COST

### Availability

LATICRETE materials are available worldwide.

### For Distributor Information, Call:

Toll Free: 1.800.243.4788

Telephone: +1.203.393.0010

For on-line distributor information, visit LATICRETE at [laticrete.com](http://laticrete.com)

## Cost

Contact a LATICRETE Distributor in your area.

## 7. WARRANTY

See 10. FILING SYSTEM:

- DS 025.0: 25 Year System Warranty
- DS 230.10: 10 Year System Warranty
- DS 230.13: 1 Year Product Warranty
- DS 230.99: LATICRETE Lifetime System Warranty (United States and Canada)

## 8. MAINTENANCE

The non-finish or non-exposed portion of the HYDRO BAN® Shower System products require no maintenance. However, installation performance and durability may depend on properly maintaining products and finishes that cover the HYDRO BAN Shower System products and those supplied by other manufacturers. The exposed portion of the stainless steel HYDRO BAN Drains can be cleaned and maintained using a non-abrasive stainless steel cleaner or polish with a clean soft white cotton cloth. When cleaning the stainless steel or oil rubbed bronze drains contact the cleaner manufacturer if another cleaner type will be used to ensure compatibility with the drain material.

## 9. TECHNICAL SERVICES

### Technical Assistance

Information is available by calling the LATICRETE Technical Service Hotline:

Toll Free: 1.800.243.4788, ext. 1235  
Telephone: +1.203.393.0010, ext. 1235  
Fax: +1.203.393.1948

### Technical and Safety Literature

To acquire technical and safety literature, please visit our website at [laticrete.com](http://laticrete.com).

## 10. FILING SYSTEM

Additional product information is available on our website at [laticrete.com](http://laticrete.com). The following is a list of related documents:

- DS 230.13: LATICRETE Product Warranty
- DS 230.10: LATICRETE 10 Year System Warranty (United States & Canada)
- DS 025.0: LATICRETE 25 Year System Warranty (United States and Canada)
- DS 230.99: LATICRETE Lifetime System Warranty (United States and Canada)
- DS 100.0: 3701 Fortified Mortar
- DS 250.0: PERMACOLOR Grout
- DS 663.0: HYDRO BAN
- DS 677.0: 254 Platinum
- DS 681.0: SPECTRALOCK® PRO Premium Grout†
- DS 663.5: HYDRO BAN How to Instructions

---

LATICRETE International, Inc.

One LATICRETE Park North, Bethany, CT 06524-3423 USA • 1.800.243.4788 • +1.203.393.0010 • [www.laticrete.com](http://www.laticrete.com)

© 2020 LATICRETE International, Inc. All trademarks shown are the intellectual properties of their respective owners.