



# STONETECH<sup>®</sup> Maintenance & Care

## Polished Terrazzo and Agglomerate Marbles

### MCI 117

**NOTE:** For all recommended products: read the entire product label before using. Use only as directed. Always test in a small inconspicuous area with a 24-hour cure time to determine ease of application and desired results. Avoid skin and eye contact. Always wear appropriate safety equipment during product use.

#### **REGULAR MAINTENANCE AND CARE**

Routine, daily maintenance of polished terrazzo or agglomerate marble surfaces will involve keeping dirt, dust and other soiling from building up. Spills, food and other potential staining materials need to be cleaned up in a reasonable period of time. Regular sweeping and light damp mopping is advisable. For larger installations these processes remain the same; only the scale will change.

Highly alkaline, acidic, ammonia based, abrasive cleaners, or bleach may damage some stone, tile and/or grout surfaces and may also degrade an applied sealer, adversely affecting stain repellency. The use of a gentle cleaner specifically formulated for stone, tile and grout maintenance is the best assurance of not harming Polished Terrazzo or Agglomerate Marble, grout or degrading any applied sealers.

#### **Maintenance Cleaning**

Both routine damp mopping and monthly scrub cleanings of limestone surfaces can be accomplished using sponges and brushes, spray mops, and traditional mop and bucket. A wet/dry vacuum is helpful for cleaning big floors. For commercial applications a swing machine fitted with a brush or pad or an auto-scrubber will help maintain larger installations. STONETECH has two maintenance cleaners suitable for unpolished, honed or textured limestone surfaces.

#### **For routine cleaning of polished terrazzo and agglomerate marbles with a cleaner and protector:**

##### **STONETECH<sup>®</sup> Revitalizer<sup>®</sup> Cleaner & Protector (Concentrate)**

Read entire label before using. Use only as directed. Be sure all surfaces to be cleaned are swept or vacuumed to remove loose debris. Keep children and pets out of the area during application and drying.

1. Dilute STONETECH<sup>®</sup> Revitalizer<sup>®</sup> Cleaner and Protector (Concentrate) with warm water according to the following mixing chart:

Use	STONETECH <sup>®</sup> Revitalizer <sup>®</sup> Cleaner & Protector (Concentrate)	Warm Water
Spray Refill	1 part	1 part
Light Duty	1 part	4 parts

2. Apply diluted solution with a damp mop, towel, sponge or low pressure sprayer.
3. Rub surface lightly and remove any excess cleaner. No need to rinse.
4. Repeat if necessary, for heavily soiled areas.
5. Let area dry completely before using.

## **STONETECH Revitalizer Cleaner and Protector (Ready-To-Use)**

Read entire label before using. Use only as directed. Be sure all surfaces to be cleaned are swept or vacuumed to remove loose debris. Keep children and pets out of the area during application and drying.

1. To refill 24 oz. (709 mL) spray bottle, use a funnel.
2. Spray or pour directly onto soiled area.
3. Wipe clean with a dry towel, lint free cloth or sponge. No need to rinse.
4. Repeat for heavily soiled areas using a non-abrasive scrubbing pad.
5. Wipe clean with a dry towel.

Refer to [DS 212.0](#) for more information.

### **For routine cleaning of polished terrazzo and agglomerate marbles with a cleaner:**

#### **STONETECH Stone & Tile Cleaner (Concentrate)**

Read entire label before using. Use only as directed. Be sure surfaces to be cleaned are swept or vacuumed to remove loose debris. Avoid skin and eye contact with product. Wear protective eyewear and gloves when handling concentrate. Keep children and pets out of the area during application and drying.

1. Dilute STONETECH Stone & Tile Cleaner (Concentrate) with warm water according to the following mixing chart:

Use	STONETECH® Stone & Tile Cleaner (Concentrate)	Warm Water
Light Duty	1 part	64 parts
Heavy Duty	1 part	32 parts

2. Apply mixed solution with a damp mop, sponge or appropriate professional cleaning equipment.
3. Clean entire area with mop, changing cleaning solution often to ensure that soil is not redeposited. Wipe or rinse cleaned area.
4. Let area dry completely before using.

#### **STONETECH® Stone & Tile Cleaner (Ready-To-Use)**

Read entire label before using. Use only as directed. Be sure surfaces to be cleaned are swept or vacuumed to remove loose debris. Avoid skin and eye contact with product. Wear protective eyewear and gloves when handling concentrate. Keep children and pets out of the area during application and drying.

1. Spray or pour directly onto soiled area.
2. Wipe clean with a dry towel, lint free cloth or sponge. No need to rinse.
3. Repeat for heavily soiled areas using a non-abrasive scrubbing pad.
4. Wipe clean with a dry towel.

Refer to [DS 211.0](#) for more information.

### **For a brilliant shine on countertops and vanities:**

#### **STONETECH Polish**

Read entire label before using. Use only as directed. Always test in a small inconspicuous area to determine that the desired results will be achieved. Make sure surface is clean, dry and free of waxes and coatings.

1. Spray a light coat of STONETECH Polish over the entire surface.
2. Spread evenly with a clean cloth.
3. Buff until there is no visible liquid and a high shine appears.

**Note:** STONETECH Polish is not intended for floors as it may create a slipping hazard. It is not a restorative process for worn or damaged marble surfaces.

Please refer to [DS 216.5](#) for more information.

## **NEW INSTALLATION PRE-GROUT TREATMENT**

**Grouting cleanup is often easier when the stone is sealed prior to grouting. Light colored or porous polished terrazzo and agglomerate marbles are susceptible to grout staining and may benefit from sealing prior to grouting.**

A simple water test can be performed to identify if the tile is porous. If the polished terrazzo and agglomerate marbles darkens after applying water to the stone surface and waiting for 5 minutes, the tile is absorbent and applying a sealer prior to grouting may aid in clean up after grouting. On polished terrazzo and agglomerate marbles that do darken with water a single application of sealer is generally sufficient as a pre-grouting treatment.

### **For a pre-grout sealer for polished terrazzo and agglomerate marble:**

#### **STONETECH® Heavy Duty Sealer**

##### **Pre-Grout Sealer Application**

Read entire label before using. Use only as directed. Always test in a small inconspicuous area with a 24-hour cure time to determine ease of application and desired results. Make sure surface is clean and free of waxes and coatings. STONETECH® Heavy Duty Sealer may be applied to damp surfaces one hour after standing water has been removed. Surface temperature should be between 50°F - 80°F (10°C - 26°C). Ensure that the area is well-ventilated during application and until the surface is dry. Keep children and pets out of the area until treated surface is dry.

1. Ensure cap is closed and sealed and then shake well before use.
2. Mask off surfaces not intended to be treated.
3. Liberally apply an even coat of STONETECH Heavy Duty Sealer using a paint pad, roller, brush or low-pressure sprayer.
4. Allow the sealer to penetrate the surface for 10-15 minutes. During this time, keep the surface wet with sealer, adding more sealer as needed. **DO NOT ALLOW SEALER TO COMPLETELY DRY ON THE SURFACE.**
5. Thoroughly wipe dry the entire surface with clean absorbent towels.
6. A second coat may be needed for porous, absorbent surfaces. If a second coat is required, it should be applied within 30-40 minutes from the initial application as directed in steps 3-5.
7. Allow sealer to cure for 24 hours prior to grouting.
8. Clean tools used during application with water.

Refer to [DS 279.0](#) for more information.

## **RESTORATIVE DEEP CLEANING**

**Stone, tile and grout installations can become heavily soiled over time. Restorative cleaning processes will help return these surfaces to a more acceptable appearance.**

The following restorative surface cleaning processes are done in preparation for resealing or for specialized surface cleaning circumstances. These cleaning processes should not damage the surface of the polished terrazzo or agglomerate marble. However, these types of heavy duty cleaning methods may degrade or strip many sealers from the application.

Depending on the type of soiling or staining, select one of the following options:

### **For cleaning grease, oil, dirt, dry soil, or to prepare for resealing:**

## STONETECH® KlenzAll™ Cleaner (Concentrate)

Read entire label before using. Use only as directed. Always test in a small inconspicuous area to determine ease of use and desired results. Be sure all surfaces to be cleaned are swept or vacuumed to remove loose debris. Avoid skin and eye contact with product. Wear protective eyewear, gloves, long sleeves, and long pants while handling concentrate. Ensure work area is well-ventilated during application and until surface is dry. Keep children and pets out of the area during application and drying.

The following is a restorative surface cleaning process which is done in preparation for resealing or for specialized surface cleaning circumstances. This process should not damage the stone surface. However, this type of heavy duty cleaning will degrade or strip many sealers from the application.

1. Dilute concentrated STONETECH® KlenzAll™ Cleaner with warm water according to the following mixing chart:

Use	STONETECH® KlenzAll™ Cleaner (Concentrate)	Warm Water	pH
Light Duty	1 part	8 parts	10.7
Medium Duty	1 part	4 parts	11

2. Apply mixed solution with a mop, clean cloth or low-pressure sprayer. Avoid applying cleaner on unintended surfaces.
3. Lightly scrub with a scrub brush or floor machine as needed.
4. Remove STONETECH KlenzAll Cleaner using a clean cloth, wet/dry vacuum or damp mop.
5. Rinse area well with clean water. Allow area to dry completely.
6. Some surfaces may require additional cleaning. If so, repeat steps 2 – 5 above.
7. Reseal cleaned area with an appropriate STONETECH sealer (e.g. STONETECH Heavy Duty Sealer).

Refer to [DS 215.0](#) for more information.

## **Removal of cement grout hazes, stripping topical coatings, acrylic finishes or heavy waxes:**

### STONETECH® Epoxy Grout Haze & Coating Stripper

Read entire label before using. Use only as directed. Test in a small inconspicuous area to determine ease of application and desired results. Be sure all surfaces to be cleaned are swept or vacuumed to remove loose debris. Ensure work area is well-ventilated during application and until surface is dry. Keep children and pets out of the area until surface use resumes. Avoid contact with surfaces not intended to be treated. Avoid applying in direct sunlight. Should not be used in extreme temperatures. Recommended application temperature range is between 50°F - 90°F (10 °C - 32 °C).

1. SHAKE WELL BEFORE USING. Do not dilute before applying.
2. Wear rubber gloves and eye protection during handling and application to prevent skin and eye contact.
3. Liberally apply an even coat of STONETECH Epoxy Grout Haze & Coating Stripper over the required area with a paint brush, mop or paint pad. DO NOT APPLY WITH A SPRAYER. Immediately remove STONETECH Epoxy Grout Haze & Coating Stripper from unintended surfaces with a wet cloth to prevent potential damage to those surfaces.
4. Application time will vary depending on type of coating being removed. Approximate application times are as follows:

Haze / Coating	Surface Type	Age of Haze/Coating		
		24 Hour	7 Days	> 7 Days
Epoxy Grout Haze	Tile	1 – 3 minutes	3 – 5 minutes	10 minutes
Epoxy Grout Haze	Natural Stone & Masonry	1 – 3 minutes	3 – 5 minutes	10 minutes
Coatings *	Tile	1 – 5 minutes		
Coatings *	Natural Stone & Masonry	1 – 5 minutes		10 minutes

5. Do not let STONETECH® Epoxy Grout Haze & Coating Stripper dry on the surface. If STONETECH Heavy Duty Epoxy Grout Haze & Coating Stripper starts to dry, add additional product to keep surface wet.
6. Agitate surface with a nylon scrub brush or pad after testing a small area first to make sure that brush or pad will not scratch the surface. Surface can be wet with water to enable easier removal of coating.
7. Wipe up residual STONETECH Epoxy Grout Haze & Coating Stripper Coating Stripper with clean, dry cloth or wet mop. A wet/dry vacuum can be used for larger area.
8. Rinse surface well with clean water.
9. More than one application may be required, repeat steps 3 through 8 when necessary.
10. Surface traffic may begin 2 hours after removal of coating.

Refer to [DS 116.4](#) for more information.

**For spot or small area deep cleaning:**

**STONETECH® DeepKlenz™ Cleaner**

Read entire label before using. Use only as directed. Test in a small inconspicuous area to determine required results. Be sure all surfaces to be cleaned are swept or vacuumed to remove loose debris. Avoid skin and eye contact with product. Wear protective eyewear, gloves, long sleeves, and long pants while handling concentrate. Ensure work area is well-ventilated during application and until surface is dry. Keep children and pets out of the area during application and drying. Recommended application temperature range is between 40°F - 100°F (4°C - 38°C).

1. Thoroughly wet surface by directly spraying onto soiled area.
2. Allow STONETECH DeepKlenz™ Cleaner to work on the surface for 5-10 minutes. Do NOT allow product to dry on the surface.
3. Lightly scrub with a stiff bristle brush to remove the surface contaminants.
4. Rinse and wipe surface with clean cloth and warm water. Repeat as needed for heavy soiled areas.
5. Reseal cleaned area with an appropriate STONETECH sealer (e.g. STONETECH Heavy Duty Sealer).

Refer to [DS 111.2](#) for more information.

**For cleaning and removing soap scum:**

**STONETECH Soap Scum Remover**

Read entire label before using. Use only as directed. Always test in a small inconspicuous area to determine ease of use and desired results. Be sure surfaces to be cleaned are swept or vacuumed to remove loose debris. Avoid skin and eye contact. Wear protective eyewear and gloves. Keep children and pets out of the area during application and drying.

1. Spray STONETECH Soap Scum Remover directly on soiled areas. Avoid applying onto unintended surfaces.
2. Wipe surface with clean, dry cloth or scrub with stiff nylon brush as needed.
3. Rinse area well with clean water.

4. Wipe area dry with clean cloth.
5. Repeat as needed for heavily soiled areas.

Refer to [DS 229.0](#) for more information.

### **For cleaning and removing mold and mildew:**

#### **STONETECH® Mold & Mildew Stain Remover**

Read entire label before using. Use only as directed. Always test in a small inconspicuous area to determine ease of use and desired results. Be sure surfaces to be cleaned are swept or vacuumed to remove loose debris. Avoid skin and eye contact. Wear protective eyewear and gloves. Keep children and pets out of the area during application and drying. Do not mix this product with other household cleaners or metals.

1. Spray STONETECH® Mold & Mildew Stain Remover directly on soiled areas. Avoid applying onto unintended surfaces.
2. Clean surface with non-abrasive sponge or stiff nylon brush as needed.
3. Rinse area well with clean water.
4. Repeat as needed for heavily-soiled areas.

Refer to [DS 219.0](#) for more information.

### **For oil stain removal:**

#### **STONETECH Oil Stain Remover**

Read entire label before using. Use only as directed. Always test in a small inconspicuous area to determine that the desired results will be achieved. Make sure surface is clean, dry, and free of waxes and coatings. Ensure that area is well-ventilated and keep children and pets away from the area during application and until surface is clean and dry.

1. Using a plastic or wood spatula, stir thoroughly to mix the paste.
2. Apply a ¼” (6 mm) thick layer of paste to the stain. Ensure that the paste extends at least 1” - 2” (25 – 50mm) beyond the edge of the stain.
3. Do not cover.
4. Allow 48 – 72 hours for STONETECH Oil Stain Remover to dry.
5. Using a plastic spatula, remove the dried STONETECH Oil Stain Remover and discard.
6. Allow solvent to completely dry from the stone.
7. If stain is not completely gone after drying, repeat process.
8. Clean up residue and tools with mineral spirits.
9. Once the surface is dry, reseal the cleaned area with an appropriate STONETECH® sealer (e.g. STONETECH Heavy Duty Sealer).

Refer to [DS 214.0](#) for more information.

### **Mechanical Refinishing for polished terrazzo or agglomerate marbles**

#### **STONETECH Honing & Polishing Powders**

This refinishing process is designed for scratch, etch and wear pattern removal and will restore the stone’s surface to a uniform finish and shine. Depending on the severity of the wear or damage to the stone use, in succession, one or more of the grit levels (180/280/400/600/800) of the STONETECH Honing Powders bringing the stone up to an even, uniform 800 grit finish. After the honing steps, follow with the STONETECH Polishing Powder to create the final shine.

Refinishing requires using a hand-held low speed sander/polisher or an orbital sander for counters, walls or floor edges. For floors use a weighted, 175 rpm floor machine (130 - 140 lb. [59.1 – 63.6]). Hand machines and floor machines need to be fitted with a natural hair pad or a white nylon polishing pad.

Read entire label before using. Use only as directed. Always test in a small inconspicuous area to determine ease of application and desired results. Allow new grout installations to cure for a minimum of 72 hours prior to application. Make sure surface is clean, dry and free of waxes and coatings.

**For refinishing to a polished finish:**

1. If surface is heavily soiled, pre-clean with STONETECH® KlenzAll™ Cleaner if needed.
2. Mask off and protect any baseboards or adjacent areas to avoid splashing and overspray onto surfaces not intended to be treated.
3. If you are using a variety of abrasive grits, ensure that the surface is well rinsed and a new pad is used for each changeover.
4. Apply approximately 1/2 cup (118 mL) STONETECH Honing Powder plus 1 cup (237 mL) clean water directly onto the stone surface.
5. Refinish using a hand orbital sander or weighted floor machine at 130-140 lbs. (59.1-63.6 kg), 175 rpm, fitted with a natural hair pad.
6. Keep compound wet while refinishing with plenty of water. Add STONETECH Honing Powder as needed.
7. Use successively higher numbered grits of STONETECH Honing Powder to close the face of the stone and follow with STONETECH Polishing Powder applied as in steps 5-10 above. Repeat as needed to achieve the desired level of shine.
8. Rinse well and use a wet vacuum or hot water extraction unit to remove all remaining compound.
9. Clean equipment with water.
10. Reseal polished area with an appropriate STONETECH sealer (e.g. STONETECH Heavy Duty Sealer). Refer to [DS 225.5](#) and [DS 224.5](#) for more information.

**SEALING AND PROTECTING:**

Polished terrazzo and agglomerate marbles are susceptible to staining from both oil and water-based materials and sealing will help protect the stone's appearance. The cement grouts used in polished terrazzo or agglomerate marble tile installations will also be more stain resistant with the application of a penetrating sealer.

**For natural looking protection for polished terrazzo and agglomerate marbles and grout installations:**

**STONETECH Heavy Duty Sealer**

Read entire label before using. Use only as directed. Always test in a small inconspicuous area with a 24-hour cure time to determine ease of application and desired results. Allow new grout installations to cure for a minimum of 72 hours prior to application. Make sure surface is clean and free of waxes and coatings. Sealer may be applied to damp surfaces one hour after standing water has been removed. Surface temperature should be between 50°F - 80°F (10°C - 26°C). Ensure that the area is well-ventilated during application and until the surface is dry. Keep children and pets out of the area until treated surface is dry.

1. Ensure cap is closed and sealed and then shake well before use.
2. Mask off surfaces not intended to be treated.
3. Liberally apply an even coat using a paint pad, roller, brush or low-pressure sprayer.
4. Allow sealer to penetrate the surface for 10-15 minutes. During this time, keep the surface wet with sealer, adding more sealer as needed. **DO NOT ALLOW SEALER TO COMPLETELY DRY ON THE SURFACE.**
5. Thoroughly wipe dry the entire surface with clean absorbent towels.
6. A second coat may be needed for porous, absorbent surfaces. If a second coat is required, it should be applied within 30-40 minutes from the initial application as directed in steps 3-5.
7. Should a sealer residue appear, rewet the impacted section of the surface with sealer. Agitate the surface with a white nylon scrubbing pad to loosen residue and wipe dry with a clean, absorbent towel.

8. A full cure is achieved in 24-72 hours. Use of the treated surface may resume in 6-8 hours. If use of the surface must resume sooner, cover the treated surface with red rosin paper to protect it until full cure is achieved.
  9. Clean tools used during application with water.
- Refer to [DS 279.0](#) for more information.

Maintenance & Care Instructions are subject to change without notice. For latest revision, check our website at <https://laticrete.com>  
MCI 117 R 20 February 2020



---

**LATICRETE INTERNATIONAL, INC.** ▪ 1 LATICRETE Park North ▪ Bethany, CT 06524-3423 USA  
800.243.4788 ▪ [support@laticrete.com](mailto:support@laticrete.com) ▪ [www.laticrete.com](http://www.laticrete.com)

©2015 LATICRETE INTERNATIONAL, INC. All trademarks shown are the intellectual properties of their respective owners.