



SPARTACOTE[®] Guard PURE Flooring

Installation Guideline

TDS 434

LATICRETE International, Inc. strongly recommends the use of licensed coating contractors who have demonstrated their commitment to their craft and taken the time to stay current with the latest materials and methods. Requiring references and a portfolio along with a bid or estimate is a good way to ensure the contractor has successfully completed work of similar size, scope, and complexity. Please read application instructions in their entirety prior to installation and contact LATICRETE with any question before you begin any coating project.

LATICRETE resinous flooring products are manufactured with the highest regard for quality, functionality and performance. The following provides a guideline to the proper installation of the SPARTACOTE[™] Guard PURE[™] flooring system. To install the SPARTACOTE Guard PURE Flooring system you should follow the installation guidelines below:

SUBSTRATE PREPARATION:

Always mechanically prepare (profile) the surface. An open, porous surface is necessary for proper bonding. The surface must be deemed structurally and mechanically sound, clean, and dry. Proper surface preparation is required for decorative concrete, thin-film “Class-A-type” flooring systems. This is best achieved with mechanical grinding machines using diamond heads achieving a final 30 to 100-grit profile. Recommended surface profile is a CSP-2, Reference ICRI Technical Guideline No. 03732. Surfaces to be coated must be free of previous coatings, sealers, grease, and other contaminants that may impede adhesion. Always check the surface for any bond inhibitors prior to application. **DO NOT USE Alcohol** to clean or tack substrate or previous coat prior to application. Any repairs must be addressed prior to application and should be repaired in accordance with ICRI standards. A moisture emission measurement system is necessary to assess the moisture drive of a concrete slab prior to installation of any toppings or coatings. The maximum amount of moisture in the concrete/mortar bed substrate should not exceed 3 lbs./1,000 ft² (170 µg/s•m²)/24 hrs per ASTM F1869 or 75% relative humidity as measured. If there is a moisture emission situation in excess of the above rate, the use of SPARTACOTE Moisture Vapor Barrier will be necessary prior to the application of the floor coating.

APPLICATION METHODS:

All methods require the use of 18” (45.7cm) 3/8” (9mm) nap soft woven roller covers, 6” (15.2cm) weenie rollers and/or 3” (7.6cm) chip brushes. All methods described below will incorporate a “cut-in” around the perimeter. The cut in should stay just ahead of the main floor application. Product should be dry to the touch in 1-2 hours following application. Material may be applied using one of the following techniques:

Perimeter Cut-In:

Some systems require the use of 6” (152mm) weenie rollers and/or 3” (76mm) chip brushes to effectively “cut-in” around the perimeter of the project. The cut in should stay just ahead of the main floor application.

Dip & Roll:

The dip and roll technique will incorporate the use of an 18” (45.7cm) roller and pan. After pouring your already mixed material into your roller pan, fully saturate the roller. Apply the material in one direction followed by a perpendicular back roll in the opposite direction. This method works well if you’re working in sections that stop at a control joint.

Ribbon & Roll:

The ribbon and roll technique will consist of pouring the mixed material out in a “ribbon” approximately 8 -12” (22.3 - 30.5cm) wide by the length of the area to be coated. While standing over the ribbon spread the material using an 18” (45.7cm) roller. This should be done working in an area approximately 8 ft. (2.4 m) wide (ribbon should be placed in the center of the area in which you are working) moving your way down the length of the ribbon while ensuring an even,

uniform application of the material. The next ribbon should be placed in the center of the next 8 ft. (2.4 m) section and 4 ft. (1.2 m) from the “wet edge” of your previous application.

Top/ Seal Coat Broom & Roll:

For larger square footage installation, applicators may find it advantageous to incorporate an asphalt seal-coat broom. Pour a ribbon of material at the back wall or starting point, spread the material using the broom (exactly as you would with a notched squeegee).

MIXING MATERIAL

Pigmenting Coatings:

Disperse a 1 quart (0.9 L) SPARTACOTE® Polyaspartic Pigment pack into 1 gallon (3.8 L) SPARTACOTE FLEX PURE™ Part A pigment base (short-filled). Mix pigment into part A with a slow drill mixer for approximately 2 minutes until the pigment is properly dispersed. Failure to do so will result in a potentially uneven finish. Once pigment is fully dispersed, use a separate mixing vessel combine the newly pigmented part A with the Part B at a 1:1 ratio (by volume) for 2 minutes with a slow speed drill or paddle mixer making sure to scrape the sides and bottom of the bucket. Avoid creating a vortex, as it will induce air to the mix.

Non-Pigmented Clear Coats:

Do not mix until ready for immediate use. Using a separate mixing vessel combine the SPARTACOTE FLEX PURE parts A&B at a 1:1 ratio (by volume) for 2 minutes with a slow speed drill or paddle mixer making sure to scrape the sides and bottom of the bucket. Avoid creating a vortex, as it will induce air to the mix.

APPLYING THE PRODUCT

Application of Primer Coat: Following surface preparation, be certain that the substrate is free of any excessive concrete dust, moisture or other contaminants. An 8 mil (0.2 mm) thick coat of SPARTACOTE FLEX PURE pigmented should be installed at a rate of 200 ft²/ gallon (18.6 m²/ 3.8 L) using one of the suggested application methods above. Remember to always complete the application with a back-roll. Allow coat to dry before the mid coat is to be applied, typically 2-3 hours.

Application of Second/ Mid Coat: Apply a second 8 mil (0.2mm) thick coat of SPARTACOTE FLEX PURE pigmented using an application method mentioned above, at a rate of 200 ft²/ gallon (18.6 m²/ 3.8 L). Optional: SPARTACOTE GRIP™ Traction Additive may be used in the second coat to provide for increased texture and traction. SPARTACOTE GRIP Traction Additive is a polymer sand that can be suspended into the material during the mixing process. Amount added can range from 1-3 oz/gallon (30-89 mL/ 3.8 L) depending on the desired level of traction. Always do a mock-up to establish desired level of traction.

Application of Top Coat: Top coat will consist of a single coat of SPARTACOTE FLEX PURE clear applied at a rate of 200 ft²/gallon (18.6m²/ 3.8 L). SPARTACOTE FLEX PURE top coat material can be applied using any of the methods described above. (Dip and roll, ribbon and roll, Sparta-broom and roll, or squeegee and roll. SPARTACOTE FLEX PURE Optional: SPARTACOTE GRIP traction additive may be used in the top coat to provide for increased texture and traction.

CURE/ POST COMPLETION:

The floor should be monitored for two hours to prevented foot traffic and should remain out of service for 24 hours before returning the normal use. LATICRETE polyaspartic floor coating systems are non-porous, causing dirt and contaminants to remain on the surface. However, these contaminants can act as abrasives and if not removed regularly can mar the finish on the floor over time. Refer to [TDS 420](#) for information regarding Recommended Maintenance of your flooring system.

Technical Data Sheets are subject to change without notice. For latest revision, check our website at <https://laticrete.com>
TDS 434.doc R 13 February 2020



LATICRETE INTERNATIONAL, INC. ▪ 1 LATICRETE Park North ▪ Bethany, CT 06524-3423 USA
800.243.4788 ▪ support@laticrete.com ▪ www.laticrete.com

©2014 LATICRETE INTERNATIONAL, INC. All trademarks shown are the intellectual properties of their respective owners.