



SPARTACOTE™ Quartz PURE Flooring

Installation Guideline

TDS 438

LATICRETE International, Inc. strongly recommends the use of licensed coating contractors who have demonstrated their commitment to their craft and taken the time to stay current with the latest materials and methods. Requiring references and a portfolio along with a bid or estimate is a good way to ensure the contractor has successfully completed work of similar size, scope, and complexity. Please read application instructions in their entirety prior to installation and contact LATICRETE with any question before you begin any coating project.

LATICRETE resinous flooring products are manufactured with the highest regard for quality, functionality and performance. The following provides a guideline to the proper installation of the SPARTACOTE™ Quartz PURE flooring system. To install the SPARTACOTE Quartz PURE flooring system you should follow the installation guidelines below:

SUBSTRATE PREPARATION:

Always mechanically prepare (profile) the surface. An open, porous surface is necessary for proper bonding. The surface must be deemed structurally and mechanically sound, clean, and dry. Proper surface preparation is required for decorative concrete, thin-film “Class-A-type” flooring systems. This is best achieved with mechanical grinding machines using diamond heads. Recommended surface profile is a CSP-2, Reference ICRI Technical Guideline No. 03732. Surfaces to be coated must be free of previous coatings, sealers, grease, and other contaminants that may impede adhesion. Always check the surface for any bond inhibitors prior to application. DO NOT USE Alcohol to clean or tack substrate or previous coat prior to application. Any repairs must be addressed prior to application and should be repaired in accordance with ICRI standards. A moisture emission measurement system is necessary to assess the moisture drive of a concrete slab prior to installation of any toppings or coatings. The maximum amount of moisture in the concrete/mortar bed substrate should not exceed 3 lbs. /1,000 ft² (170 µg/s m²)/ 24 hrs. per ASTM F-1869 or 75% relative humidity as measured. If there is a moisture emission situation in excess of the above rate, the use of SPARTACOTE™ Moisture Vapor Barrier will be necessary prior to the application of the floor coating requiring an ICRI- CSP 3-5.

APPLICATION METHODS:

All methods require the use of 18” (45.7cm) 3/8” (9mm) nap soft woven roller covers, 6” (15.2cm) weenie rollers and/or 3” (7.6cm) chip brushes. All methods described below will incorporate a “cut-in” around the perimeter. The cut in should stay just ahead of the main floor application. Product should be dry to the touch in 1-2 hours following application. Material may be applied using one of the following techniques:

Perimeter Cut-In:

Some systems require the use of 6” (15.2cm) weenie rollers and/or 3” (7.6cm) chip brushes to effectively “cut-in” around the perimeter of the project. The cut in should stay just ahead of the main floor application

Dip & Roll:

The dip and roll technique will incorporate the use of an 18” (45.7cm) roller and pan. After pouring your already mixed material into your roller pan, fully saturate the roller. Apply the material in one direction followed by a perpendicular back roll in the opposite direction. This method works well if you’re working in sections that stop at a control joint.

Ribbon & Roll:

The ribbon and roll technique will consist of pouring the mixed material out in a “ribbon” approximately 8 -12” (22.3 -30.5cm) wide by the length of the area to be coated. While standing over the ribbon spread the material using an 18” (45.7cm) roller. This should be done working in an area approximately 8 ft. (2.4 m) wide (ribbon should be placed in the center of the area in which you are working) moving your way down the length of the ribbon while ensuring an even, uniform application of the material. The next ribbon should be placed in the center of the next 8 ft. (2.4 m) section and 4 ft. (1.2 m) from the “wet edge” of your previous application.

Top/ Seal Coat Broom & Roll:

For larger square footage installation, applicators may find it advantageous to incorporate an asphalt seal-coat broom. Pour a ribbon of material at the back wall or starting point, spread the material using the broom (exactly as you would with a notched squeegee).

Installation Guides are subject to change without notice. For latest revision, check our website at www.laticrete.com

MIXING MATERIAL

Pigmenting Coatings:

Disperse a 1-qt (0.9L) SPARTACOTE™ Polyaspartic Pigment pack into 1-gallon (3.8L) SPARTACOTE™ FLEX PURE™ Part A pigment base (short-filled). Mix pigment into part A with a slow drill mixer for approximately 2 minutes until the pigment is properly dispersed. Failure to do so will result in a potentially uneven finish. Once pigment is fully dispersed, use a separate mixing vessel combine the newly pigmented part A with the Part B in equal 1:1 amounts by volume for 2 minutes with a slow speed drill or paddle mixer making sure to scrape the sides and bottom of the bucket. Avoid creating a vortex, as it will induce air to the mix.

Non-Pigmented Clear Coats:

Do not mix until ready for immediate use. Using a separate mixing vessel combine the SPARTACOTE™ FLEX PURE™ parts A&B in equal 1:1 amounts by volume for 2 minutes with a slow speed drill or paddle mixer making sure to scrape the sides and bottom of the bucket. Avoid creating a vortex, as it will induce air to the mix.

APPLYING THE PRODUCT

Application of Primer / Broadcast Coat: Following surface preparation, be certain that the substrate is free of any excessive concrete dust, moisture or other contaminants. A coat of SPARTACOTE™ FLEX PURE™ pigmented should be installed at a rate of 200 ft²/ gallon (18.6 m²/ 3.8L) using one of the suggested application methods above. Immediately following the finish back roll a third person on spikes will broadcast the quartz aggregate into the wet resin to refusal or rejection. Coverage rate for the quartz aggregate is approximately 5 ft² per pound (0.2 m²/kg) or 250 ft² (23.2 m²) per bag. (It is recommended that extra aggregate be on hand to avoid running short).

Cleaning and Removing Excess Quartz: Once broadcast coat has dried to the touch, begin removing excess quartz. NOTE: The floor is dry and can be walked on but is not “cured” at this point. Walk cautiously, do not run or twist feet on the surface. A stiff bristled broom or vacuum can also be used to ensure excess quartz is removed. Carefully clean up the excess quartz and re-box it as it can be used again on future projects and/or the next broadcast coat. **If a single broadcast is desired or a solid-color quartz system is being installed, proceed to grout coat.**

Application of Second Broadcast Coat: Apply a coat of SPARTACOTE FLEX PURE Clear, using some of the methods described above at a rate of 150 ft²/ gallon (13.9 m²/ 3.8L). For best results use a flat squeegee. Do not use a broom. Immediately following the finish back roll a third person on spikes will broadcast the quartz aggregate into the wet resin to refusal or rejection. Coverage rate for the quartz aggregate is approximately 5 ft² per pound (0.2 m²/ kg) or 250 ft² (23.2m²) per bag. (It is recommended that extra aggregate be on hand to avoid running short). Allow coat to dry prior to the application of the top coat, typically 2-3 hours.

Cleaning and Removing Excess Quartz: Once broadcast coat has dried to the touch, begin removing excess quartz. NOTE: The floor is dry and can be walked on but is not “cured” at this point. Walk cautiously, do not run or twist feet on the surface. A stiff bristled broom or vacuum can also be used to ensure excess quartz is removed. Carefully clean up the excess quartz and re-box it as it can be used again on future projects and/or the next broadcast coat. **If a single broadcast is desired or a solid-color quartz system is being

Application of Grout Coat: Apply the grout coat of SPARTACOTE FLEX PURE Clear, at a rate of 150 ft²/ gallon (9.3 m²/ 3.8L). For best results, apply the material using a flat squeegee although additional methods described above would work. The grout coat is used to lock the previously applied quartz aggregate in place. DO NOT USE the top seal coat broom method to apply this coat.

Application of Top Coat: Top coat application follows the same method as the grout coat application. This coat coverage rate can be adjusted up or down to accommodate the desired level of traction. The use of SPARTACOTE FLEX PURE clear is recommended for standard and low application thickness. If a faster walk-on time is sought, the use of SPARTACOTE™ FLEX XT™ is recommended.

**For solid-color quartz systems, substitute SPARTACOTE FLEX PURE Clear with SPARTACOTE FLEX PURE pigmented or SPARTACOTE FLEX XT Pigmented. **

CURE/ POST COMPLETION:

The floor should be monitored for two hours to prevented foot traffic and should remain out of service for 24 hours before returning the normal use. LATICRETE polyaspartic floor coating systems are nonporous, causing dirt and contaminants to remain on the surface. However, these contaminants can act as abrasives and if not removed regularly can mar the finish on the floor over time. Refer to TDS420 for information regarding recommended maintenance of your flooring system.

Installation Guides are subject to change without notice. For latest revision, check our website at www.laticrete.com

R 25 November 2018



LATICRETE INTERNATIONAL, INC. ▪ 1 LATICRETE Park North ▪ Bethany, CT 06524-3423 USA
800.243.4788 ▪ support@laticrete.com ▪ www.laticrete.com

©2010 LATICRETE INTERNATIONAL, INC. LATICRETE, LATAPOXY, SPECTRALOCK and the  logo are Registered Trademarks of LATICRETE International, Inc.