




Using the STRATA_HEAT Wi-Fi Thermostat without Wi-Fi Connection TDS 266

STRATA_HEAT floor heating system is one of the most advanced radiant underfloor heating systems available in the market today. The system consists of a high-performance floor heating wire, an uncoupling mat, choice of thermostats, and the world's first heat conductive thin-set additive (optional). The system provides you with one of the most advanced and efficient floor systems for your installation but sometimes you want to stick to the basics. This guide was created for customers who simply want the system to work from the device without having to connect the unit to the home or office Wi-Fi network.



When setting the unit up for the first time please proceed as follows:

1. Choose System Type and accept by clicking .
2. Choose Input (01- to read Air Temp) or (02- to read Floor Temp) and accept by clicking .
3. On the Wi-Fi screen click the to highlight the blue and accept by clicking .
4. Enter the Current Date and be sure to click between each selection.
5. Choose your Hour Format (12H/ 24H) by using / and accept by clicking .
6. Enter Current Time and be sure to click between each selection.
7. After the Time is accepted you will see a appear on the screen and the unit is ready for use.
8. Simply use the / to select a temperature, accept by clicking .

Technical Data Sheets are subject to change without notice. For latest revision, check our website at <https://laticrete.com>
TDS 266.doc R 08 December 2022

LATICRETE International, Inc.

One LATICRETE Park North, Bethany, CT 06524-3423 USA ■ 1.800.243.4788 ■ +1.203.393.0010 ■ www.laticrete.com

©2020 LATICRETE International, Inc. All trademarks shown are the intellectual properties of their respective owners.