



POLYASPARTIC PIGMENTS

DS-862-0621

**Globally Proven
Construction Solutions**



1. PRODUCT NAME

POLYASPARTIC PIGMENTS

2. MANUFACTURER

LATICRETE Europe S.r.l. a socio unico
Via Paletti, snc, 41051
Castelnuovo Rangone MO, Italy
Telephone: +39 059 535540
Email: info@laticreteurope.com
Website: laticrete.eu

3. PRODUCT DESCRIPTION

POLYASPARTIC PIGMENTS are designed to be used exclusively with the GUARD PA, GUARD PA PURE, and GUARD PA PURE CLINICAL PLUS polyaspartic coating products.

Available in 14 standard colors and custom colour options (RAL colours), these materials are manufactured through a proprietary process in which raw pigments are ground and subsequently combined with the highest quality polyaspartic resins available.

Once ready for use, these concentrated pigments are dispersed directly into short-filled part A pigment base.

Advantages

- 14 standard colours, including safety colours
- Custom colour matching available
- UV stable, suitable for exterior applications
- Excellent colour retention
- Easy to use, on-site pigment dispersion system

Suitable Substrates

- Polyaspartic Coating

Packaging

- 1,25 lt
- 4,70 lt

Available Colours

- | | |
|---------------|-----------------|
| - Light Grey | - Light Brown |
| - Medium Grey | - Black |
| - Dark Grey | - Dark Blue |
| - Light Beige | - Tile Red |
| - Sand Beige | - Bright Green |
| - Dark Beige | - Safety Yellow |
| - White | - Safety Red |

Custom colours available upon request.

Shelf Life

Three years unopened. Store at 40°F to 75°F (4°-24°C) in a covered area (out of the sun). Maintain a consistent storage temperature prior to application. Material should be kept in a cool dry place prior to application.

Limitations

Refer to data sheet for applicable LATICRETE® polyaspartic coating Product Datasheets (GUARD PA, GUARD PA PURE, GUARD PA PURE CLINICAL PLUS).

Cautions

Refer to Safety Data Sheet (SDS) for additional details.

- Mock-ups and field test areas are required in order to validate performance and appearance related characteristics (including but not limited to colour, inherent surface variations, wear, anti-dusting, abrasion resistance, chemical resistance, stain resistance, coefficient of friction, etc.) to ensure system performance as specified for the intended use, and to determine approval of the decorative flooring system.

4. TECHNICAL DATA



Working Properties

Refer to data sheet for applicable LATICRETE® polyaspartic coating Product Datasheets (GUARD PA, GUARD PA PURE, and GUARD PA PURE CLINICAL PLUS).

Specifications subject to change without notification. Results shown are typical but reflect test procedures used. Actual field performance will depend on installation methods and site conditions.

5. INSTALLATION

Maintain a consistent storage temperature prior to application. Material should be kept in a cool dry place prior to application. Use only with GUARD PA, GUARD PA PURE and GUARD PA PURE CLINICAL PLUS polyaspartic coatings.

Add full contents of POLYASPARTIC PIGMENTS directly into short-filled Part A pigment base. Mix pigment into Part A with a slow speed drill mixer for 2 minutes to fully disperse the resin pigments. Failure to properly mix pigments may lead to an inconsistent finish and reduced product performance.

6. AVAILABILITY AND COST

Availability

LATICRETE® materials are available worldwide. For distributor information, please contact LATICRETE Europe S.r.l. a socio unico:

+39 059 535540

info@laticreteurope.com

For on-line distributor information, visit www.laticrete.eu.

Cost

Contact LATICRETE Europe S.r.l. a socio unico to obtain complete information and cost.

7. WARRANTY

The supplier warrants that the product will not deteriorate under normal conditions and use. The warranty validity of one (1) year. Contact Technical Services for further information. See 10. FILING SYSTEM:

- DS230.13EU: 1 Year Product Warranty (EN)

9. TECHNICAL SERVICES

Technical Assistance

Information is available by calling or emailing the Technical Service Hotline:

+39 059 535540

technicalservices@laticreteurope.com

Technical and Safety Literature

To obtain technical and safety literature, please visit our website at www.laticrete.eu.

Warning

The information and the instructions in the data sheet, although based on knowledge gained through years of applications, are indicative. LATICRETE® is unable to directly control the installation methods and conditions of products and does not assume any liability arising from their implementation. Those who want to use LATICRETE® products should conduct adequate tests to determine the site specifications. Results shown are typical but reflect test procedures used. Actual field performance will depend on installation method and site conditions.

LATICRETE® products are covered by a warranty within the limits of what is established by our general conditions of sale and within the limits of correspondence related to technical specifications and applicable certifications, as expressly indicated in the product data sheets, documentation, or applicable technical documentation.

10. FILING SYSTEM

Additional product information is available on our website at laticrete.eu. The following is a list of related documents:

- DS 230.13EU: 1 Year Product Warranty
- DS 864: GUARD PA Product Datasheet
- DS 866: GUARD PA PURE Product Datasheet
- DS 870: GUARD PA PURE CLINICAL PLUS Product Datasheet